


RP-7 Type Pressure Reducing Valve (for Steam)


Used in **Food processing** **Sterilizing** **Cleaning equipments** for clean steam

1 PRESSURE REDUCING VALVES (FOR STEAM)

RP-7 Type is a compact, pilot operated-type pressure reducing valve for application on equipments or devices with comparatively small flow.
It is small, light-duty (MAX.50% according to our data) and can be installed as a part of a machine.



CONSTRUCTION




FEATURES

- Features
 - Piston guide and special seal ring allow stable control over small flow and rated flow of fluid.
- Easy pressure adjustment by manual handle with automatic lock mechanism.
- Compact design.

SPECIFICATIONS

Model name		RP-7	
		RP7-F □	RP7-J □
Code name		※ L(low press.) or H (high press.) For adjustable secondary pressure is required in □.	
Size		15 · 20 · 25 (1/2" · 3/4" · 1")	
Applicable fluid		Steam	
Applicable primary pressure		Max. 1.6MPa	
Adjustable secondary pressure		L: 0.03~0.4MPa, H: 0.3~0.8MPa	
Maximum reducing rate		20:1	
Minimum pressure differential across the disc		0.05MPa	
Lock up pressure		Max. 0.02MPa	
Offset pressure		Within 0.02MPa(Adjustable secondary pressure 0.03~0.035MPa) Within 0.03MPa(Adjustable secondary pressure 0.035~0.07MPa) Within 0.05MPa(Adjustable secondary pressure 0.07~0.8MPa)	
Leakage allowance		Less than 0.05% of rated flow	
Cv value		Size 15mm:1, Size 20mm:2, Size 25mm:3	
Applicable temperature		Max. 220 °C	
End connection		Screwed JIS Rc	
Materials	Body	Cast bronze	
	Disc & seat	Stainless steel	
	Piston & cylinder	Cast bronze	Stainless steel
Valve body pressure test		Twice as much pressure of flange rated pressure	

NOMINAL DIAMETER SELECTION CHART (for Steam)




Example 1:
Primary pressure: 0.4MPa (saturated steam)
Secondary pressure: 0.2MPa
Flow: 80 kg/h
At the above conditions, the nominal diameter should be size 20 mm.
At the same conditions and at 200 °C, the nominal diameter is also size 20 mm.

Example 2:
Primary pressure: 1.0MPa (saturated steam)
Secondary pressure: 0.05MPa
Flow: 250 kg/h
At the above conditions, the nominal diameter should be size 25 mm.


DATA/RP-Type Pressure Reducing Valve (RP-6, 8, 1H, 2H Type Series) (for Steam or Gases)

■ FLOW CHARACTERISTICS



■ PRESSURE CHARACTERISTICS

Example: RP-6 Type



The secondary pressure is set at 0.2 MPa when primary pressure is 0.3 MPa. The chart shows the change of secondary pressure when primary pressure changes between 0.3~1.0~0.3 MPa.

■ TERMS

- **Primary pressure:** The inlet pressure of pressure reducing valve or the inlet pressure of piping that is near to pressure reducing valve.
- **Secondary pressure:** The outlet pressure of pressure reducing valve or the outlet pressure of piping that is near to pressure reducing valve.
- **Set pressure:** secondary pressure at minimum adjustable flow.
- **Offset pressure:** The difference between secondary pressure and set pressure when primary pressure is kept at a constant level but flow increases gradually from minimal adjustable flow to the rated flow of pressure reducing valve.
- **Lockup pressure:** The increased pressure above set pressure when the secondary valve of pressure reducing valve is locked up.
- **Minimum adjustable flow:** The minimum flow of pressure reducing valve for maintaining stable flow.
- **Rated flow:** The maximum flow at the specified offset pressure when primary pressure is kept at a constant level.

■ TIPS:HOW TO SELECT AN APPROPRIATE NOMINAL DIAMETER?

- ① When you select the size, use nominal diameter selection chart. Considering pressure loss and thermal loss, the flow amount for selecting the nominal diameter should be larger by 10-20% than designed flow amount, particularly in case of the pressure reducing ratio is large or the set pressure is lower than 0.1MPa.
- ② The secondary pressure of a pressure reducing valve changes when primary pressure or flow changes. Therefore, when selecting nominal diameter, it is necessary to consider lockup pressure and offset.
- ③ In the case when primary and secondary pressure are not constant but change within a certain range, the nominal diameter can be determined using the primary and secondary pressures that produce the smallest differential pressure.
- ④ In the case the pressure reduction ratio exceeds its maximum value, it is required to perform two-step pressure reduction by using 2 pressure reducing valves. Although the flow at step 1 and step 2 are the same, the nominal diameter of the valve at step 1 should be different from that at step 2, because primary pressure is different from secondary pressure. Therefore, it is necessary to select two nominal diameters for the valves to be used.
- ⑤ It is easy to understand that an extremely small valve allows only a tiny flow. However, this does not mean a large valve is better than small valve. In fact, an extremely large valve may cause the occurrence of "hunting", which can lead to abnormal wearing. Another thing to be noted is the minimum adjustable flow, which is about 5% of the rated flow. You should not select a valve which may be used when the flow is lower than the minimum adjustable flow. In winter or summer, flow may change extremely. It is recommended that you install two pressure reducing valves, a large one and a smaller one, and switch between them according to change of flow.

(See flow characteristics and pressure characteristics.)

DATA/Pressure Reducing Valve (for Steam or Gases)

■ INSTALLATION EXAMPLE

Fig.1 With bypass piping





Fig.2 Without bypass piping



■ POINTS FOR INSTALLATION

- Installation of pressure reducing valve and piping.
- 1. Pressure reducing valve should be vertical to horizontal piping
- 2. Install safety valve or safety relief valve on the secondary side of pressure reducing valve.
 - ※ 1. Equipment may be damaged due to increase of secondary pressure at the time of failure of pressure reducing valve.
 - ※ 2. See Table 1 for set pressure of safety valve and safety relief valve.
 - ※ 3. In the case safety valve or safety relief valve is used as an alarm, its nominal diameter should be big enough to allow discharge of 10% maximum flow of pressure reducing valve, which is about the leakage of pressure reducing valve. In very few cases, safety valve or safety relief valve may allow discharge of maximum flow of pressure reducing valve.(reference value: see Table 2 and Table 3).

TABLE2. FLOW FOR SAFETY RELIEF VALVE (Saturated steam)

SL-37~SL-40 TYPE (kg/h)

Set pressure (MPa)	Size(mm)					
	15(½")	20(¾")	25(1")	32(1¼")	40(1½")	50(2")
0.05	13.4	22.9	33.3	61.8	96.7	157
0.1	17.4	29.7	43.1	80	125	203
0.2	25.3	43.2	62.8	116	182	296
0.3	34.1	58	84.3	156	244	397
0.4	41.9	71.4	103	192	301	489
0.5	50.5	86	125	231	362	589
0.6	59	100	146	271	424	689
0.7	67.6	115	167	310	485	788
0.8	76.1	129	188	349	546	886
0.9	84.7	144	209	388	608	988
1.0	93.2	158	230	428	669	1080

TABLE1. SET PRESSURE FOR SAFETY RELIEF VALVE

(MPa)

Set pressure of Pressure reducing valve	Set pressure of Safety valve
0.1 or less	+ 0.05
Over 0.1 and below 0.4	+ 0.08
0.4 or more and below 0.6	+ 0.12
0.6 or more and below 0.8	+ 0.15
0.8 or more and below 1.0	+ 0.19
1.0 or more and 1.2 or less	+ 0.23

Add the above value to set pressure of the Pressure Reducing Valve.

TABLE3. FLOW FOR SAFETY RELIEF VALVE (Air)

SL-37~SL-40 TYPE (kg/h)

Set pressure (MPa)	Size(mm)					
	15(½")	20(¾")	25(1")	32(1¼")	40(1½")	50(2")
0.05	21.8	37.1	53.9	100	156	254
0.1	28.2	48	69.8	129	202	329
0.2	41	69.9	101	188	294	479
0.3	55.1	93.9	136	253	396	643
0.4	69.3	118	171	318	497	808
0.5	83.4	142	206	382	598	972
0.6	97.5	166	241	447	700	1130
0.7	111	190	276	512	801	1300
0.8	125	214	311	577	902	1460
0.9	139	238	346	641	1000	1630
1.0	154	262	381	706	1100	1790

3. Install strainer at the primary side of pressure reducing valve.
4. For devices that cannot be stopped, install bypass piping (with stop valve) from the primary side to the secondary side of pressure reducing valve. If bypass piping is not suitable, then install blowing stop valve, which is derived from the main pipe before the primary side of pressure reducing valve, so as to make flushing possible.
5. Install straight piping, stop valve, and pressure gauge before and after pressure reducing valve.
 - If end connection of pressure reducing valve is realized using screw, then use union joint to make it easy to fix and remove.
 - ※ The diameter of piping before and after pressure reducing valve should be determined based on the standard velocity of flow of fluid. Generally, since the nominal diameter of secondary piping of pressure reducing valve for steam and gasses is larger than the diameter of pressure reducing valve, it is necessary to use reducer.
6. If you install solenoid valve (on/off operation) or control valve at the secondary side of pressure reducing valve, there should be an interval (L) between such solenoid valve or control valve and pressure reducing valve. The interval (L) should be larger than 2m in the case of solenoid valve. As for control valve, the interval should be larger than 1m if nominal diameter is less than 100mm, and larger than 1.5m if nominal diameter is larger than 125mm(see Fig.3).
7. In the case of 2-step pressure reduction, the interval between 2 valves should be 1~2m (see Fig.4).

Fig.3 INTERVAL BETWEEN PRESSURE REDUCING VALVE AND CONTROL VALVE





Fig.4 INTERVAL BETWEEN VALVES (2-STEP PRESSURE REDUCTION)



DATA/Pressure Reducing Valve (for Steam or Gases)

8. For pressure reducing valve for steam, “hunting” or vibration may occur if drain accumulates.
- To prevent hunting and vibration, it is necessary to prevent drain from entering into the piping or install stem trap at the primary side.
- In addition, since pressure reducing valve cannot be closed completely, it is necessary to install steam trap at the secondary side if the amount of steam used is near zero.

Fig.5: Proper installation





Fig.6: Improper installation



9. Make sure sufficient space is left for maintenance.
10. Apply appropriate support to pressure reducing valve to make sure it does not bear the weight of piping, bending force, or vibration directly.
11. If you think there is possibility of freezing, insulate or discharge the drain.

12. The secondary pressure of the valve is not adjusted at delivery. Therefore, you should adjust the secondary pressure to the desired pressure before use.


※ The secondary pressure of a non-adjusted valve is near to zero.

※ How to adjust the secondary pressure:


- 1 Close the stop valves at primary and secondary sides.
- 2 Open the blowing stop valve or stop valve in bypass and remove any content inside. Such operation is called flushing and should be carried out sufficiently by spending sufficient time on it. Take care not to make the secondary pressure rise excessively.
- 3 Close the stop valve in by pass or blowing stop valve completely.
- 4 Make sure there is not any spring load caused by adjusting screw.
- 5 Open the stop valve at primary side gradually.
- 6 Make sure you have adjusted the secondary pressure. Open the stop valve at the secondary side slightly to allow small flow.
- 7 Apply a small spring load using handle or adjusting screw. Once the fluid start flowing, open the stop valve at the secondary side gradually.
- 8 Read the pressure gauge and apply more spring load to make the pressure reaching the set pressure. The pressure rises if you turn the handle or adjusting screw in the right direction and falls if you turn them in the left direction.
- 9 Once the desired pressure is reached, use the lock nut to lock the adjusting screw. After the screw is locked, the spring load will not change.

• ADJUSTING SECONDARY PRESSURE

For RP-6 series and RD-40 series.



• OTHER PRESSURE REDUCING VALVES



■ DIAMETER OF PIPING BEFORE AND AFTER PRESSURE REDUCING VALVE

The nominal diameter of pressure reducing valve can be determined using relevant graphs made for such purpose. The diameter of piping before and after pressure reducing valve must be determined base on the standard velocity of fluid.

Extremely small diameter or large velocity of fluid may cause large loss of pressure inside the piping and wearing, vibration of the piping. Therefore, it is necessary to consider the standard velocity of fluid when determining the diameter of piping.

● Table of velocity of Steam as standard condition.

Item	For steam	Standard velocity (m/s)
Pipeage	Saturated steam (0.2~0.5MPa)	15~20
	Saturated steam (0.5~1.5MPa)	20~30
(Steam engine)	Saturated steam	20~30
	Super heated steam	30~40

● Table of velocity of Air as standard condition.

Item	For air	Standard velocity(m/s)
Pipeage	(0.1~0.2MPa)	8~15
	(20~30MPa)	5~7
(Compressor)	Saturated line	10~20
	Low pressure supplyline	20~30
	High pressure supply line	10~15